* 1 : 1GR-FE
* 2 : 2TR-FE
* 3 : 1KD-FTV
* 4 : 5L-E
* 5 : w/ Engine Immobiliser System
* 6 : Before Aug. 2008 Production
* 7 : From Aug. 2008 Production
* 8 : Except *3 *7
* 9 : w/ VSC
*10 : w/ ABS w/o VSC

(BAT)
7. 5A
OBD
14 2D
G (*7)
O (*6)
16
BAT
D 3
DLC3
Junction
Connector
W (*9)
R (*9)
6
14
CANH
CANL
D 3
DLC3
TAC
WFSE
TS
SIL
TC
A/B
SG
CG
9
15
12
7
13
11
5
4
B-W
W (*1, *2)
W (*3)
W (*9)
W (*10)
R-Y
P-B
B-Y (w/ SRS)
BR
G
W (*3 A/T)
R-Y (*3 *7)
R-Y (*8)
R-Y (*3 A/T)
6 2O
22 2O
6 2N
10 2C
11 2C
9 2C
11 ID2
9 ID2
2 ID2
8 ID2
18 ID2
4 II5
7 II3 (*6)
4 II5 (*7)
6 2Q
5 2Q
22 2Q
21 2Q
5 2O
6 2P
6 2J
5 2J
7 2B
4 2B
3 2B
22 2P
5 A
2 B
9
7
1
6
4
1 A
1 C
4 D
7 E
29 B
35 C
19 D
4 F
23 B
17 C
11 D
15 F
30 B (*1)
13 C (*2)
18 D (*3)
15 F (*4)
33
15
14
16
16
15
14
9
23 B
24 B
7
CPU
C10
Combination
Meter
TACH
WFSE
TC
SIL
E 4(D), E 9(C),
E13(A), E14(B), E22(E), E23(F)
Engine ECU
TS
S25
Skid Control ECU
with Actuator
TS
D/G
TC
S 2
Skid Control ECU
with Actuator
SIL
TC
LA
A24
Airbag Sensor
Assembly Center
D
T21
Transponder
Key ECU
SIL
WFSE
T18(B)
Transmission
Control ECU
BR (*3 *7)
BR (*4)
V (*2)
V (*1)
W-B (*3 *6)
W-B (*3 *7)
J45(A), J46(B)
Junction
Connector
J 8
Junction
Connector
J38
Junction
Connector
J29
Junction
Connector
EE
EM
ED
EF
IH