
* 1 : Before Aug. 2008 Production
* 2 : From Aug. 2008 Production
(BAT)
25A EFI
10A STOP
(IG)
7. 5A IGN
10A ETCS
(ST)
7. 5A ST
MAIN Relay
J 5(A), J 6(B) Junction Connector
S14 Stop Lamp SW
N 1 Park/Neutral Position SW
J39(A), J40(B) Junction Connector
A22 Accelerator Position Sensor
VCP2 VPA2 EPA2 VCPA VPA EPA
D 3 DLC3
SIL TC WFSE
PL RL NL DL 2L LL RB
J17(A), J18(B) Junction Connector
E13(A), E14(B), E15(C), E16(D), E17(E) Engine ECU
MREL +B +B2 BATT STP ST1- IGSW +BM NSW STA VCP2 VPA2 EPA2 VCPA VPA EPA SIL TC WFSE R D 3 2 L
NT- NT+ SP2+ SP2- VC VTA1 VTA2 M+ M- GE01 THW VG E2G THA E2 THO1 THO2 S1 S2 SR SLT+ SLT- SLU+ SLU- SL2+ SL2- SL1+ SL1- E04 E05 E03 ME01 E1 E01 E02 4WD TFN L4 NE- NE+ SPD OILW 4
J 2 Junction Connector
J 1 Junction Connector
T27 Transmission Revolution Sensor (Input)
T28 Transmission Revolution Sensor (Output)
J39(A) Junction Connector
(Shielded)
T 1 Throttle Body Assembly
W 1 Water Temp. Sensor
A 4 Air Flow Meter
E 1(A) ECT Solenoid
OT+ OT2+ OT- OT2-
T 4 Transfer Indicator SW (Center Diff. Lock)
T 6 Transfer Indicator SW (Neutral Position)
T 5 Transfer Indicator SW (L4 Position)
J41 Junction Connector
C 5(A) Crankshaft Position Sensor
(4WD)
S11 Shift Lock Control ECU
Transmission Control SW
NSSD NSSL AT2 ATL ATD AT4
C10(A), C11(B) Combination Meter
A/T OIL TEMP
CPU
Speedometer
7. 5A MET
7. 5A DOME
10A ECU-IG&GAUGE
S 3 Speed Sensor
IG+ SI SE
J28(A), J29(B) Junction Connector
J38 Junction Connector
EB EE EF IG