
* 3 : Unleaded Gasoline
* 4 : Leaded Gasoline
* 1 : w/ Headlight Beam Level Control
* 2 : w/o Headlight Beam Level Control
* 3 : Unleaded Gasoline
* 4 : Before Jul. 2007 Production M/T, From Jul. 2007 Production
* 5 : Before Jul. 2007 Production A/T
* 6 : Before Aug. 2008 Production
* 9 : From Aug. 2008 Production
* 5 : w/ Engine Immobilizer System
* 6 : Before Jul. 2007 Production M/T, From Jul. 2007 Production
* 7 : Before Jul. 2007 Production A/T
* 8 : Before Aug. 2008 Production
* 9 : From Aug. 2008 Production
E 8(A), E 9(B), E10(C), E11(D) Engine ECU
(BAT) 25A EFI
MAIN Relay
C/OPN Relay
(IG) 7.5A IGN
10A STOP
10A ETCS
(BAT) 10A TAIL
20A DEF
(ST) 7.5A ST
10A IN2
7.5A CMD
(BAT) 7.5A MET
7.5A DOME
10A ECU-IG&IG2
30A ECU-B
S14 Stop Lamp SW
S13 Clutch Start SW
S15 Back-up Lamp SW
C13(A) Combination SW
A 4 Air Flow Meter
E2 Throttle Body Assembly
V 6 Variable Resistor
A22 Accelerator Position Sensor
N 1 Park/Neutral Position SW
A13(C) Alternator
A24 Airbag Sensor Assembly Center
C10 Combination Meter
CPU
Data Link Connector 3
Tachometer
Speedometer
Fuel Gauge
Water Temp.
Odometer
Trip Meter
Fuel Level Warning
Oil Pressure Warning
Charge Warning
Brake Warning
Door Warning
Seat Belt Warning
Airbag Warning
ABS Warning
Cruise Control Warning
Immobilizer Warning
A/T Warning
Malfunction Indicator Lamp
Fuel Level Sensor
Fuel Pump Control Module
Fuel Pump
Fuel Injector No. 1
Fuel Injector No. 2
Fuel Injector No. 3
Fuel Injector No. 4
Fuel Pressure Solenoid
Purge VSV
Vapor Pressure Sensor
Canister Pump Module
Heated Oxygen Sensor (Bank 1 Sensor 1)
Heated Oxygen Sensor (Bank 1 Sensor 2)
Knock Sensor
Camshaft Position Sensor
Crankshaft Position Sensor
Ignition Coil (No. 1)
Ignition Coil (No. 2)
Ignition Coil (No. 3)
Ignition Coil (No. 4)
Igniter
Park/Neutral Position SW
Transponder Key ECU
Transponder Key Coil
Speed Sensor
Junction Connector
Wire Harness
(Shielded)