* 1 : Before Aug. 2008 Production
* 2 : From Aug. 2008 Production
80A GLOW
GLOW Relay
G 1(B) Glow Plug
25A EFI
MAIN Relay
J 5(A), J 6(B) Junction Connector
J 1 Junction Connector
7. 5A IGN
10A STOP
7. 5A ST
S14 Stop Lamp SW
J43 Junction Connector
F10 Fuel Temp. Sensor
I 7(B) Intake Air Temp. Sensor (Air Cleaner)
W 1 Water Temp. Sensor
M 3 Manifold Absolute Pressure Sensor
J45(A), J46(B) Junction Connector
E20(A), E21(B), E22(C), E23(D) Engine ECU
T33 Timing Control Valve
T31 Throttle Body Assembly
T32 Throttle Position SW
S24 Spill Control Valve
J46(B) Junction Connector
I12 Injection Pump Assembly
E19 Engine Speed Sensor
C 5(C) Crankshaft Position Sensor
J43 Junction Connector
A22 Accelerator Position Sensor
A14 A/C Amplifier
7. 5A OBD
D 3 DLC3
J26(B) Junction Connector
7. 5A MET
7. 5A DOME
10A ECU-IG&GAUGE
C10 Combination Meter
Check Engine
Glow
Speedometer
Tachometer
Temp.
CPU
J38(A), J39(B) Junction Connector
S 3 Speed Sensor
J45(A), J46(B) Junction Connector