(IG)
(BAT)
(BAT)
10A ECU-IG& GAUGE
40A IG1
25A DOOR
P 6(A), (B) Power Window Master SW
P 6(A), (B) Power Window Master SW
BW E B U D PLS PLS2 GND VCC U D U D U D
R-L
W-R
LG (*1)
L-B (*1)
W-B
L
R
L-R
P-G (*1)
B (*1)
L-O (*1)
BR (*1)
R-L
G-W
R-B
G-B
R-Y
G-Y
J22(A), J23(B) Junction Connector
J32(A), J33(B) Junction Connector
J22(A), J23(B) Junction Connector
J19(A), J20(B) Junction Connector
IG1 Relay
30A PWR
J21 Junction Connector
J34 Junction Connector
IF
II
M
P 7 Power Window Regulator Motor (Front LH)
P 7 Power Window Regulator Motor (Front LH)
P11 Power Window SW (Front Passenger's Side)
P13 Power Window SW (Rear RH)
P12 Power Window SW (Rear LH)
P 8 Power Window Regulator Motor (Front RH)
P10 Power Window Regulator Motor (Rear RH)
P 9 Power Window Regulator Motor (Rear LH)
Up
Down
(*3)
(*4)

* 1 : w/ Driver's Window Jam Protection
* 2 : w/o Driver's Window Jam Protection
* 3 : Before Aug. 2008 Production
* 4 : From Aug. 2008 Production