(IG)
(BAT)
(BAT)
10A ECU-IG& GAUGE
40A IG1
25A DOOR
P 6(A), (B) Power Window Master SW
P 6(A), (B) Power Window Master SW
BW E B PLS PLS2 GND VCC U D U D U D U D
R-L
W-R
LG (*1)
L-B (*1)
W-B
L
P-G (*1)
B (*1)
L-O (*1)
BR (*1)
B
L-R
R-L
G-W
R-Y
G-Y
R-B
G-B
J22(A), J23(B) Junction Connector
J32(A), J33(B) Junction Connector
P 8 Power Window Regulator Motor (Front RH)
P 8 Power Window Regulator Motor (Front RH)
IG1 Relay
30A PWR
W-G
W-B (*4)
W-B (*3)
J21 Junction Connector
J34 Junction Connector
J22(A), J23(B) Junction Connector
J19(A), J20(B) Junction Connector
IF
II
P11 Power Window SW (Front Passenger's Side)
P12 Power Window SW (Rear LH)
P13 Power Window SW (Rear RH)
Up
Down
R
L-R
P 7 Power Window Regulator Motor (Front LH)
P 9 Power Window Regulator Motor (Rear LH)
P10 Power Window Regulator Motor (Rear RH)

* 1 : w/ Driver's Window Jam Protection
* 2 : w/o Driver's Window Jam Protection
* 3 : Before Aug. 2008 Production
* 4 : From Aug. 2008 Production