

F RELAY LOCATIONS

: Driver Side J/B	Instrument Panel Brace RH (See Page 21)




(from Instrument Panel Wire)
2O
PWR OUT Relay
40A AM1 (for High Current)
40A IG1 (for High Current)
HTR Relay
Gray
2N
(from Instrument Panel Wire)
2Q
Gray
(from Instrument Panel Wire)
2P
(from Instrument Panel Wire)
Integration Relay
2R
Gray
2S
(from Instrument Panel Wire)
(from Instrument Panel Wire)