

W3
N1
T28
N2
T4
S3
T6
T5
V4
W1
T27
T14
T15
V3
S2
J1
S1
J2
P2
T13
S5
K3
P1
K4
T1
S6
S7
S4
R1
T12
W2

J 1 Junction Connector
J 2 Junction Connector

K 3 Knock Control Sensor (Bank 1)
K 4 Knock Control Sensor (Bank 2)

N 1 Park/Neutral Position SW
N 2 Noise Filter (Ignition)

P 1 Power Steering Oil Pressure SW
P 2 Pressure SW

R 1 Rear Washer Motor


S 1 Security Horn
S 2 Skid Control ECU with Actuator
S 3 Speed Sensor
S 4 Speed Sensor (Front LH)
S 5 Speed Sensor (Front RH)
S 6 Starter
S 7 Starter

T 1 Throttle Body Assembly
T 4 Transfer Indicator SW (Center Diff. Lock)
T 5 Transfer Indicator SW (L4 Position)
T 6 Transfer Indicator SW (Neutral Position)
T 12 Turn Signal Lamp (Front LH)
T 13 Turn Signal Lamp (Front RH)
T 14 Turn Signal Lamp (Front Side LH)
T 15 Turn Signal Lamp (Front Side RH)
T 27 Transmission Revolution Sensor (Input)
T 28 Transmission Revolution Sensor (Output)


V 3 VSV (Purge)
V 4 VSV (ACIS)

W 1 Water Temp. Sensor
W 2 Windshield Washer Motor
W 3 Windshield Wiper Motor


J 1
White




J 2
White




K 3
Black



K 4
Black



N 1
Gray



N 2
Gray




(1GR-FE, 2TR-FE Before Aug. 2008 Production)

P 1
Black




P 2
Gray



(South Africa Production)


R 1
Black



S 1
Black




S 2
Black




S 3
Black



S 4
Gray



S 5
White




S 6
Black




(1GR-FE, 2TR-FE, 1KD-FTV)

S 7




(1GR-FE)


T 1
Black




T 4
Blue




T 5
Blue




T 6
Gray



T 12
Gray



T 13
Gray




T 14
Gray




T 15
Gray




T 27
Black



T 28
Black




V 3
Gray



(1GR-FE)


V 4
Brown



W 1
Black



W 2
Black



W 3
Black

