

B1
G1
B3
B2
F9
F3
H2
C3
H1
I7
A2
A13
A12
H4
C4
H3
F2
A11
H7
H6
E3
I12
E19
F10
C5
A10
F1

A 2 A/C Compressor
A 10 Airbag Sensor (Front LH)
A 11 Airbag Sensor (Front RH)
A 12 Alternator
A 13 Alternator

B 1 Back-Up Lamp SW
B 2 Brake Fluid Level Warning SW
B 3 Brake Vacuum Warning SW

C 3 Clearance Lamp (Front LH)
C 3 Clearance Lamp (Front LH)
C 4 Clearance Lamp (Front RH)
C 4 Clearance Lamp (Front RH)
C 5 Crankshaft Position Sensor

E 3 Engine Oil Pressure SW
E 19 Engine Speed Sensor

F 1 Fog Lamp (Front LH)
F 2 Fog Lamp (Front RH)
F 3 Fuel Filter Warning SW
F 9 Fuel Sedimentary Level Warning SW
F 10 Fuel Temp. Sensor

G 1 Glow Plug

H 1 Headlamp (LH High)
H 2 Headlamp (LH Low)
H 2 Headlamp (LH Low)
H 3 Headlamp (RH High)
H 4 Headlamp (RH Low)
H 4 Headlamp (RH Low)
H 6 Horn (High)
H 7 Horn (Low)

I 7 Inlet Air Temp. Sensor
I 12 Injection Pump Assembly

A 2
Gray




A 10
Yellow



A 11
Yellow




A 12




(5L-E)

A 13
Black



(5L-E)

B 1
Gray



(1GR-FE, 1KD-FTV, 5L-E)

B 2
Gray




B 3
Gray




(Before Aug. 2008 Production)

C 3
Black




(Before Aug. 2008 Production Except 2TR-FE, From Aug. 2008 Production Except South Africa)

C 3
Gray




(Before Aug. 2008 Production 2TR-FE, From Aug. 2008 Production South Africa)

C 4
Black



(Before Aug. 2008 Production Except 2TR-FE, From Aug. 2008 Production Except South Africa)

C 4
Gray



(Before Aug. 2008 Production 2TR-FE, From Aug. 2008 Production South Africa)

C 5
Black




(5L-E)

E 3
White




(5L-E)


E 19
White




F 1
Brown



F 2
Brown



F 3
Black




F 9
Gray



F 10
Dark Gray




G 1



(5L-E)


H 1

Black



H 2


Brown



(Before Aug. 2008 Production)

H 2


Black



(From Aug. 2008 Production)


H 3

Black



H 4


Brown



(Before Aug. 2008 Production)

H 4


Black



(From Aug. 2008 Production)


H 6

Black



H 7

Black



I 7

Black



I 12

Black

