

M2
O3
F20
B14
D5
D9
C16
O2
D8
D4
D11
B12
B10
D7
B11
C25
F19
F11
D10
D6
F12
F14
(*1)
F13
(*2)
A29
J36
J37
D14
B9
L2
* 1:1GR-FE, 2TR-FE
* 2:5L-E, 1KD-FTV

A 29 ABS Deceleration Sensor

B 9 Back Door Lock Assembly
B 10 Blower Motor (Rear)
B 11 Blower Resistor (Rear)
B 12 Blower SW (Rear)
B 14 Blower SW (Rear)

C 16 Center Stop Lamp
C 25 Clearance Warning ECU

D 4 Door Courtesy SW (Driver's Side)
D 5 Door Courtesy SW (Front Passenger's Side)
D 6 Door Courtesy SW (Rear LH)
D 7 Door Courtesy SW (Rear RH)
D 8 Door Lock Assembly (Driver's Side)
D 9 Door Lock Assembly (Front Passenger's Side)
D 10 Door Lock Assembly (Rear LH)
D 11 Door Lock Assembly (Rear RH)
D 14 Diff. Lock Shift Actuator Assembly

F 11 Front Seat Inner Belt Assembly (Driver's Side)
F 12 Front Seat Inner Belt (Front Passenger's Side)
F 13 Fuel Sender Gage
F 14 Fuel Suction Pump and Gage Assembly
F 19 Front Seat Outer Belt (LH)
F 20 Front Seat Outer Belt (RH)


J 36 Junction Connector
J 37 Junction Connector

L 2 License Plate Lamp


M 2 Map Lamp

O 2 Outer Rear View Mirror (LH)
O 3 Outer Rear View Mirror (RH)


A 29
Black




B 9
White




B 10
Black




B 11
Black




B 12
White




B 14
White



C 16
White



C 25
White



D 4
White



D 5
White




D 6
White




D 7
White




D 8
White




D 9
White



D 10
White




D 11
White




D 14
Black



F 11
White



F 12
White




F 13
Black




F 14
Black




F 19
Yellow




F 20
Yellow




J 36
White



J 37
White




L 2
White



M 2
White



O 2
White



O 3
White

