

(BAT)
30A
PWR SEAT
1
1K
G
9
IJ2
G
6
A
J58(A), J59(B)
Junction
Connector
8
B
G
1
F23
Front Power Seat Switch RH
B
Rear
Reclining
Front
Down
Lifter
Up
Rear
Slide
Front
RCLR
RCLF
LDWN
LUP
SLDR
SLDF
E
2
BR
4
BB2
BR
1
M
2
F25
Front Power Seat Reclining
Position Motor Assembly RH
3
P
1
BB2
P
7
V
8
W
2
M
1
F22
Front Power Seat Lift
Position Motor Assembly RH
6
Y
9
L
1
M
2
F21
Front Power Seat Slide
Position Motor Assembly RH
4
W-B
1
B
J58(A), J59(B)
Junction
Connector
5
A
W-B
10
J21
Junction
Connector
IF