■ LIGHT REMINDER SYSTEM

- The light reminder system is provided as standard equipment for all models.
- When the ignition switch is turned from ON to ACC or OFF while the driver door is open with the headlight turned ON, this system warns the driver that the lights remain ON by sounding the buzzer. The buzzer is located inside the combination meter.

▶ System Diagram ◀

